





















Manufacturer	SLRC-1	SLRC-1Z	SLRC-2	SLRC-3	SLRC-4
					
<b>Canon</b>					
BF Twin					
EOS 3		X	X	X	X
EOS 5D	X	X	X	X	X
EOS 10D	X	X	X	X	X
EOS 20D	X	X	X	X	X
EOS 1D Mark II N			X	X	
EOS 1Ds Mark II			X	X	
EOS 1D Mark III			X	X	
EOS 30D	X	X	X	X	X
EOS Rebel K2	X	X	X	X	X
EOS-300D	X	X	X	X	X
EOS Rebel XT	X	X	X	X	X
EOS Rebel Xti	X	X	X	X	X
PowerShot G1	X				
PowerShot G2	X				
PowerShot G3	X				
PowerShot G5	X				
PowerShot G6	X				
PowerShot G7					
PowerShot Pro1	X				
PowerShot Pro90 IS	X				
PowerShot S1 IS	X				
PowerShot S2 IS	X				
PowerShot S3 IS	X				
<b>Casio</b>					
Exilim Pro505	X	X	X	X	X
Exilim Pro600					
Exilim Pro700					
QV-3500EX	X				
QV-5700	X				
Finepix S2 Pro	X	X	X	X	X
Finepix S3 Pro		X	X	X	X
Finepix S5 Pro	X	X	X	X	X
Finepix S304	X	X	X	X	X
Finepix S700	X				
Finepix S5000	X	X	X	X	X
Finepix S5200	X	X	X	X	X
Finepix S5600 Zoom	X	X	X	X	X
Finepix S5700	X				
Finepix S602 Pro	X	X	X	X	X
Finepix S6000	X		X	X	X
Finepix S6000 fd	X		X	X	X
Finepix S6500fd	X		X	X	X
Finepix S7000	X	X	X	X	X
Finepix S9000	X		X	X	X
Finepix S9100	X		X	X	X
Finepix S9500 Zoom	X	X	X	X	X
Finepix S9600	X	X	X	X	X
<b>HP</b>					

Manufacturer	SLRC-1	SLRC-1Z	SLRC-2	SLRC-3	SLRC-4
					
PhotoSmart 850	X	X			
PhotoSmart 935					
PhotoSmart 945	X	X	X	X	X
PhotoSmart E327					
<b>Kodak</b>					
EasyShare DX6340					
EasyShare DX6440					
EasyShare DX6490	X	X	X	X	X
EasyShare DX7440					
EasyShare DX7590	X	X	X	X	X
EasyShare DX7630					
EasyShare P712	X	X	X	X	X
EasyShare P850	X	X	X	X	X
EasyShare P880	X	X	X	X	X
EasyShare Z612	X	X	X	X	X
EasyShare Z650	X	X	X	X	X
EasyShare Z700	X	X	X	X	X
EasyShare Z710					
EasyShare Z730					
EasyShare Z740	X	X	X	X	X
EasyShare Z7590	X	X	X	X	X
EasyShare Z760					
<b>EZ200</b>					
<b>Leica</b>					
C-Lux 1					
<b>CM</b>					
D-Lux					
Digilux 3	X	X	X	X	X
Digilux					
M7	X	X	X	X	X
M8	X	X	X	X	X
MP	X	X	X	X	X
Minilux-Zoom					
R8		X	X	X	X
R9		X	X	X	X
V-Lux 1		X	X	X	X
<b>Nikon</b>					
Coolpix 5200					
Coolpix 5400					
Coolpix 5600					
Coolpix 5700	X	X	X	X	X
Coolpix 5900					
Coolpix 8400					
Coolpix 8700	X	X	X	X	X
Coolpix 8800	X	X	X	X	X
Coolpix 885					
D100	X	X	X	X	
D200	X	X	X	X	
D2H			X	X	
D2Hs			X	X	

Manufacturer	SLRC-1	SLRC-1Z	SLRC-2	SLRC-3	SLRC-4
					
D2X			X	X	
D40	X	X	X	X	X
D40x	X	X	X	X	X
D50	X	X	X	X	X
D70	X	X	X	X	X
D70s	X	X	X	X	X
D80	X	X	X	X	X
F100	X	X	X	X	
F5			X	X	
F65	X	X	X	X	X
FM3A	X	X	X	X	X
<b>Olympus</b>					
Camedia C-4000	X	X	X	X	X
Camedia C-4000Z		X	X	X	
Camedia C-450 Zoom					
Camedia C-480 Zoom					
Camedia C-500 Zoom					
Camedia C-5000					
Camedia C-5050	X	X	X	X	X
Camedia C-50Z					
Camedia C-7070	X	X	X	X	X
Camedia C-720 Ultra Zoom	X	X	X	X	X
Camedia C-750	X	X	X	X	X
Camedia C-765 Ultra Zoom	X	X	X	X	X
E-1	X	X	X	X	X
Evolt E-330	X	X	X	X	X
Evolt E-410	X	X	X	X	X
Evolt 300/500	X	X	X	X	X
Evolt E-510	X	X	X	X	X
Camedia E20P	X	X	X	X	X
SP-310					
SP-320					
SP-350					
SP-500 Zoom	X	X	X	X	X
SP-510	X	X	X	X	X
SP-550	X				
SP-700					
<b>Panasonic</b>					
Lumix DMC-F1					
Lumix DMC-F7-s					
Lumix DMC-FX01					
Lumix DMC FX3s					
Lumix DMC-FX5					
Lumix DMC-FX07					
Lumix DMC-FZ1B	X	X	X	X	X
Lumix DMC-FZ5	X	X	X	X	X
Lumix DMC-FZ7	X	X	X	X	X
Lumix DMC-FZ8	X				
Lumix DMC-FZ50		X	X	X	X
Lumix DMC-L1K	X	X	X	X	X

Manufacturer	SLRC-1	SLRC-1Z	SLRC-2	SLRC-3	SLRC-4
					
Lumix DMC-F7B1S					
Lumix DMC-LC20B					
Lumix DMC-LC40B	X	X	X	X	X
Lumix DMC-LC5B					
Lumix DMC FZ30	X	X	X	X	X
Lumix DMC FZ7	X	X	X	X	X
Lumix DMC LC1	X	X	X	X	X
Lumix DMC LS2					
Lumix DMC LS70					
Lumix DMC LX1					
Lumix DMC LX2					
<b>Pentax</b>					
IST D	X	X	X	X	X
IST DL	X	X	X	X	X
IST Ds	X	X	X	X	X
K10D	X	X	X	X	X
K100D & K110D	X	X	X	X	X
MZ-60	X	X	X	X	X
<b>Samsung</b>					
Digimax GX-1 L	X	X	X	X	X
Digimax GX-1 S	X	X	X	X	X
Digimax GX-10	X	X	X	X	X
Digimax 815	X	X	X	X	X
<b>Sony</b>					
A100	X	X	X	X	X
CD 400	X	X	X	X	X
CyberShot DSC-F707		X	X	X	
Cybershot DSC-G1					
CyberShot DSC-H1	X	X	X	X	X
CyberShot DSC-H2					
CyberShot DSC-R1		X	X	X	
Cybershot DSC-S30					
Cybershot DSC-S50					
Cybershot DSC-S60					
CyberShot DSC-S600					
CyberShot DSC-S650					
Cybershot DSC-S700					