

Using Your Lap Organizer

Thank you for purchasing this Case Logic® accessory.

Note: Always refer to your vehicle's User/Operators Guide for any restrictions that should be observed when adding/using any accessory.

Your new Lap Organizer is easy to attach, adjust and remove. Please check that you have the following:

Components

<u>Item</u>	<u>Description</u>	<u>Quantity</u>
1.	Black Lap Organizer	1
2.	Adjustable Hook & Loop Straps	2

Note: This accessory meets all flammability requirements of the California Bureau of Home Furnishings Bulletin 116 and 117. However, care should always be exercised near open flames or with burning cigarettes.

This accessory has been tested by an independent lab and contains NO latex.

MLO-1 / 10-2565001601

REV 06/05

Installing / Adjusting Your Lap Organizer

1. While seated in the vehicle, secure one of the adjustable hook and loop straps around either the left side of the seat or left arm tube. The hook and loop side of the paddle-shaped end should face up in your lap. Repeat the process on the opposite side.
2. Place the Lap Organizer on top of the paddle-shaped ends on your lap and ensure that the zippered pouches and logos are facing you.
3. Adjust the hook and loop straps as desired for a comfortable fit.
4. To remove the Lap Organizer, pull it away from the hook and loop adjustable straps before attempting to get out of the vehicle.

Caution: Mount the Lap Organizer securely so that it does not interfere with the functionality of the vehicle.
Do not allow the Lap Organizer to interfere with getting in or out of the vehicle.
Do not use with items that do not properly and securely fit into the case.
This item is not a restraining device and should not be strapped around user's waist or legs.

Warranty and Customer Service:

For a 5-year quality guaranty replacement, return this accessory, along with receipt to:

Case Logic Inc.
6303 Dry Creek Parkway
Longmont Colorado 80503 USA

For Customer Service Information please contact Case Logic at 1-800-925-8111

Note: Case Logic is not responsible for any damage or loss to, or theft of, personal items placed within this accessory, or any personal injury or property damage arising from, or relating to, the use of this accessory.